


Doka framed formwork Frami S





Contents	Page
Introduction	2
Basic safety warnings.....	4
Product description.....	6
 Wall formwork.....	 7
Wall formwork with Frami	7
Method statement.....	8
The Frami panel in detail	14
The logical system-grid	16
Adaptability.....	19
Joining gangs	20
Form-tie system.....	22
Length adjustment using fillers.....	25
90 degree corners	32
Acute and obtuse-angled corners	38
Shaft formwork	40
Inter-panel connections for increased tensile loads	43
Bulkhead formwork.....	46
Wall junctions	48
Vertical stacking of panels.....	50
Plumbing accessories	56
Pouring platforms with single brackets.....	60
Resetting by crane	62
Transporting, stacking and storing	64
 Column formwork.....	 67
Column formwork with Frami.....	67
Design of column formwork.....	68
 Footing and grade beam formwork	 73
Design of the footing and grade beam formwork	74
Frost walls	78
 General remarks	 80
Cleaning and care of your equipment	80
Frami combined with	82
Doka service offerings.....	83
 Component overview	 84

Basic safety warnings

User target groups

- This User Information booklet (Method Statement) is aimed at everyone who will be working with the Doka product or system it describes. It contains information on how to set up this system, and on correct, compliant utilization of the system.
- All persons working with the product described herein must be familiar with the contents of this manual and with all the safety instructions it contains.
- Persons who are incapable of reading and understanding this booklet, or who can do so only with difficulty, must be instructed and trained by the customer.
- The customer is to insure that the information materials provided by Doka (e.g. User Information booklets, Method Statements, Operating Instruction manuals, plans etc.) are available to all users, and that they have been made aware of them and have easy access to them at the usage location.

Remarks on this document

- This User Information booklet can also be used as a generic method statement or incorporated with a site-specific method statement.
- **Many of the illustrations in this booklet show the situation during formwork assembly and are therefore not always complete from the safety point of view.**
- **Further safety instructions, especially warnings, will be found in the individual sections of this document!**

Planning

- Provide safe workplaces for those using the formwork (e.g. for when it is being erected/dismantled, modified or repositioned etc). It must be possible to get to and from these workplaces via safe access routes!
- **If you are considering any deviation from the details and instructions given in this booklet, or any application which goes beyond those described in the booklet, then revised static calculations must be produced for checking, as well as supplementary assembly instructions.**

Rules applying during all phases of the assignment:

- The customer must ensure that this product is erected and dismantled, reset and generally used for its intended purpose under the direction and supervision of suitably skilled persons with the authority to issue instructions.
- Doka products are **ONLY** to be used in accordance with the Doka User Information booklets or other technical documentation provided by Doka.
- The stability of all components and units must be ensured during all phases of the construction work!
- The functional/technical instructions, safety warnings and loading data must all be strictly observed and complied with. Failure to do so can cause accidents and severe (even life-threatening) damage to health, as well as very great material damage.
- Fire-sources are not permitted anywhere near the formwork. Heating appliances are only allowed if properly and expertly used, and set up a safe distance away from the formwork.
- The work must take account of the weather conditions (e.g. risk of slippage). In extreme weather, steps must be taken in good time to safeguard the equipment, and the areas immediately around the equipment, and to protect employees.
- All connections must be checked regularly to ensure that they still fit properly and are functioning correctly.
It is very important to check all screw-type connections and wedge-clamped joints whenever the construction operations require (particularly after exceptional events such as storms), and to tighten them if necessary.

Assembly

- The equipment/system must be inspected by the customer before use, to ensure that it is in suitable condition. Steps must be taken to rule out the use of any components that are damaged, deformed, or weakened due to wear, corrosion or rot.
- Combining our formwork systems with those of other manufacturers could be dangerous, risking damage to both health and property. If you intend to combine different systems, please contact Doka for advice first.
- The assembly work must be carried out by suitably qualified employees of the client's.

Erecting the formwork

- Doka products and systems must be set up in such a way that all loads acting upon them are safely transferred!

Pouring

- Do not exceed the permitted fresh-concrete pressures. Excessively high pouring rates lead to formwork overload, cause greater deflection and risk causing breakage.

Stripping the formwork

- Do not strip the formwork until the concrete has reached sufficient strength and the person in charge has given the order for the formwork to be stripped!
- When stripping the formwork, never use the crane to break concrete cohesion. Use suitable tools such as timber wedges, special pry-bars or system features such as Framax S bias-cut corners.
- When stripping the formwork, do not endanger the stability of any part of the structure, or of any scaffolding, platforms or formwork that is still in place!

Transporting, stacking and storing

- Observe all regulations applying to the handling of formwork and scaffolding. In addition, the Doka lifting equipment must be used - this is a mandatory requirement.
- Remove any loose parts or fix them in place so that they cannot be dislodged or fall free!
- All components must be stored safely, following all the Doka instructions given in the relevant sections of this User Information booklet!

Regulations; occupational health & safety

- Always follow all federal, state and local safety regulations and other safety rules applying to the use of our products.

Instruction as required by EN 13374:

- If a person or object falls against, or into, the side-guard system and/or any of its accessories, the side-guard component affected may only continue in use after it has been inspected and passed by an expert.

Maintenance

- Only original Doka components may be used as spare parts.

Symbols

The following symbols are used in this booklet:



Important note

Failure to observe this may lead to malfunction or damage.



Caution / Warning / Danger

Failure to observe this may lead to material damage, and to injury to health which may range up to the severe or even life-threatening.



Instruction

This symbol indicates that actions need to be taken by the user.



Sight-check

Indicates that you need to do a sight-check to make sure that necessary actions have been carried out.



Tip

Points out useful practical tips.



Reference

Refers to other documents and materials.

Miscellaneous

We reserve the right to make alterations in the interests of technical progress.

Product description

Frami - the hand-set framed formwork for all on-site requirements

The **Doka framed formwork Frami** is a complete system which also comprises high-performance safety and workplace accessories. The Frami panels are lightweight and easy to handle, so they can be erected very quickly by hand.




Frami lets you form extremely quickly and economically, even when no crane is available. On sites with a crane, it is also possible to lift several panels at a time, in a gang-form.

The **ingenious panel size-grid** (with six different widths and four different heights of panel) makes for **optimum adaptability** to all construction-site situations.

Frami is perfectly tailored for use in the fields of residential construction and civil engineering:

- Walls
- Columns
- Footings and grade beams
- Single-sided formwork

A range of practical accessories makes work on the site a lot easier and does away with the need for costly job site improvisations.



Areas of use

Wall formwork with Frami

The **high load-bearing capacity** and **long lifespan** of the Doka framed formwork Frami make it an **economical solution** for all wall-forming tasks.

Frami 9'-0" panels are hydrostatically loadable up to a pour height of 9'-0" (2.74 m).

When the formwork is vertically stacked, the maximum permitted pressure of fresh concrete acting on the whole area is **1000 psf** (48 kN/m²).

Frami is exceptionally versatile and flexible, so you can quickly form any layout with it.


The panels can be **connected together at any point around the frame, quickly and safely**, using the Frami clamp.

Because the Frami panels have such high rigidity, you only need **2 form-ties for a pour height of 9'-0"** (2.74 m).

Any spaces left between the Frami panels are very easy to close. The system gives you a choice here between several different options, so that you can always get the best possible **length adjustment** in each case.

Frami also takes **corners, bulkheads and wall junctions** efficiently in its stride. Here too, it gives you perfect, cost-saving solutions.

Matching safety and workplace accessories make work with Frami even quicker and easier.



9777-320-01

- A** Frami panel (Page 14)
- B** Joining gangs (Page 20)
- C** Form-tie system (Page 22)
- D** Length adjustment (Page 25)
- E** 90 degree corners (Page 32)
- F** Acute and obtuse-angled corners (Page 38)
- G** Bulkhead formwork (Page 46)
- H** Vertical stacking of panels (Page 50)
- I** Plumbing accessories (Page 56)
- J** Pouring platforms (Page 60)
- K** Resetting by crane (Page 62)


Method statement

Using Frami as a manhandled formwork

The sequence shown here is based on a straight wall. As a rule, formwork set-up should start in a corner, working outward.

Transporting / handling the panels

- For offloading panels from a truck, or lifting them on-site a stack at a time, use the Frami transport hook 2.5kN and the Doka 4-part chain 3.20m (see "Transporting, stacking and storing").



Erecting the formwork

- Spray the plywood face with release agent (see "Cleaning and care").



Warning!

- The Frami panels must be securely braced in every phase of the construction work!
- Fix the first panel to the ground with a panel strut (see "Plumbing accessories"). This stabilizes the panel so that it cannot fall over.
- Use the nail-holes to fasten the panels to the ground or sills.




Caution!

Never use a sledge-hammer to plumb and align the panels!

This would damage the profiles of the panels.

- Use only proper plumbing tools (e.g. a special pry-bar) that cannot cause any damage.
- Continue lining up panels in this way, clamp them together (see "Inter-panel connections") and attach panel struts.




The gang can now be exactly plumbed and aligned.


Erecting the opposing formwork

Once the reinforcement has been placed, the formwork can be closed.


- Spray the form-facing of the opposing formwork with release agent.
- Stand up the first panel of the opposing formwork.
- Insert the form-ties (see "Form-tie system"). Now the opposing formwork is also secured against falling over.



- In the same way, continue lining up panels, clamping them together and fitting form-ties.



- Mount the pouring platform and attach end-of-platform sideguards where necessary (see "Pouring platforms with single brackets").



Pouring

- Frami 9'-0" panels are hydrostatically loadable up to a pour height of 9'-0" (2.74 m).
- When the formwork is vertically stacked, the maximum permitted pour pressure acting on the whole area is **1000 psf** (48 kN/m²).

Observe the following **guidelines**:

- Doka Calculation Guide, section headed "Concrete pressure on perpendicular formwork to DIN 18218"
- ACI 301 - "Specifications for Structural Concrete"
- ACI 309 - "Guide for Consolidation of Concrete"
- ACI 347 - "Guide to Formwork for Concrete"
- SP4 - "Formwork for Concrete"
- CAN/CSA S269.3 - "Concrete Formwork"



- Do not exceed the maximum permissible rate of placing.

- Pour the concrete.
- Make only moderate use of vibrators, carefully coordinating the times and locations of vibrator use.

Stripping



- Observe the stipulated stripping times.


- Remove the pouring platform.
- Beginning with the unbraced formwork side, take down the panels one-by-one - take out the form-ties and undo the connectors to the adjacent panel.
- Lift the panel away and clean concrete residue off the form-face (see "Cleaning and care").

Using Frami as a crane-handled formwork

The sequence shown here is based on a straight wall. As a rule, formwork set-up should start in a corner, working outward.


Transporting / handling the panels

- For offloading panels from a truck, or lifting them on-site a stack at a time, use the Frami transport hook 2.5kN and the Doka 4-part chain 3.20m (see "Transporting, stacking and storing").



Pre-assembly

- Pre-assemble gang-forms face-down on an assembly bench (see "Inter-panel connections").
- Mount the pouring platform and attach end-of-platform sideguards where necessary (see "Pouring platforms with single brackets").
- With the gang-form still flat, mount panel struts to it (see "Plumbing accessories").




Erecting the formwork

- Attach the crane suspension tackle to the Frami lifting hook (see "Resetting by crane" and the Operating Instructions for the "Frami lifting hook").

Max. load:

1100 lbs (500 kg) per Frami lifting hook

Area of formwork that can be lifted with 2 lifting hooks: approx. 270 sq.ft. (25 m²)



- Pick up the gang-form by crane.
- Spray the plywood face with release agent (see "Cleaning and care").



Warning!

- Do not allow people to ride on the formwork or platform.



Important note:

- Guiding the gang should be done with tag-lines that are long enough to keep the person who is doing the guiding out of the way of the gang.
- Fly the gang-form to its new location.

**Caution!**




Never use a sledge-hammer to plumb and align the panels!

This would damage the profiles of the panels.

➤ Use only proper plumbing tools (e.g. a special pry-bar) that cannot cause any damage.

➤ Fix the panel struts firmly to the ground (see "Plumbing accessories").

➤ Continue lining up adjacent gang-forms in this way, and clamp them together (see "Inter-panel connections").




The gang-form is now stable and can be plumbed and aligned exactly, with no need for the crane.

- Detach the gang-form from the crane.
- Use the nail-holes to fasten the panels to the ground or sills.

Erecting the opposing formwork

Once the reinforcement has been placed, the formwork can be closed.

- Spray the plywood face with release agent (see "Cleaning and care").
- Fly the opposing formwork by crane to its next location.



- Insert the form-ties (see "Form-tie system").



Before disconnecting from the crane:

- If there are no panel struts on the opposing formwork, do not disconnect the gang from the crane until a large enough number of form-ties have been installed to keep it safely in an upright position.
- Detach the gang-form from the crane (wherever possible, operate the lifting hook from the opposite pouring platform).
- Continue lining up adjacent gang-forms in this way, and clamp them together (see "Inter-panel connections").

Pouring


- Frami 9'-0" panels are hydrostatically loadable up to a pour height of 9'-0" (2.74 m).
- When the formwork is vertically stacked, the maximum permitted pour pressure acting on the whole area is **1000 psf** (48 kN/m²).

Observe the following **guidelines**:


- Doka Calculation Guide, section headed "Concrete pressure on perpendicular formwork to DIN 18218"
- ACI 301 - "Specifications for Structural Concrete"
- ACI 309 - "Guide for Consolidation of Concrete"
- ACI 347 - "Guide to Formwork for Concrete"
- SP4 - "Formwork for Concrete"
- CAN/CSA S269.3 - "Concrete Formwork"




- Do not exceed the maximum permissible rate of placing.
- Pour the concrete.
- Make only moderate use of vibrators, carefully coordinating the times and locations of vibrator use.



Stripping

-  ➤ Observe the stipulated stripping times.
- Remove any loose items from the formwork and pouring platform, or secure them firmly.
- Attach the gang-form of the unbraced formwork side to the crane (wherever possible, operate the lifting hook from the opposite pouring platform).
- Take out the form-ties and undo the connectors to the adjacent panels.



In order to speed up operations when repositioning by crane, most of the form-ties can be taken out in advance.

Warning!

However, there must be at least as many form-ties left in place as are needed to keep the gang safely in an upright position.




Warning!

The formwork tends to adhere to the concrete. When stripping the formwork, do not try to break concrete cohesion using the crane!


Risk of crane overload.

- Use suitable tools such as timber wedges or a special pry-bar to detach the formwork from the concrete.
- Pick up the gang-form and fly it to its next location. If the gang-form is "parked" prior to its next use, it must have sufficient stability (see "Plumbing accessories"). Gang-forms with only one panel strut must not be "parked" upright, but placed face-down.
- Clean residual concrete off the plywood face (see "Cleaning and care").
- Where the gang-form has panel struts and a pouring platform attached to it, first attach this gang-form to the crane, and only then detach the floor anchorages of the panel struts.




The Frami panel in detail

High load-bearing capacity



- Frami 9'-0" panels are hydrostatically loadable up to a pour height of 9'-0" (2.74 m).
- When the formwork is vertically stacked, the maximum permitted pour pressure acting on the whole area is **1000 psf** (48 kN/m²).

Form-tie holes




b ... Diameter 1 1/8" (28 mm)

- A Formwork tie protection
- B Form-facing

- Form-tie hole with formwork tie protection - this steel piece protects the form-facing and thus helps prolong the lifespan of the plywood face

Dimensionally stable steel hollow-profile frame




a ... 3 1/2" (9.2 cm)

- A Frame profile
- B Continuous hardware slot for inter-panel connectors
- C Formwork sheet
- D Silicone sealing strip

- Dimensionally stable hollow profiles
- Hot-dip galvanized for long life
- Strong cross-profiles
- Edge faces are easy to clean - so panels always abut tightly
- All-round hardware slot for fastening clamps at any point required
- Edges of formwork sheet are protected by frame profile
- Cross boreholes for corner configurations and bulk-heads

Accessories are easy to fasten in the cross profile



- A Frami S panel
- B Frami wedge clamp
- C Frami universal waling


Clean concrete faces

- The high-grade, 5/8" (16 mm) thick, all-birch, film-coated plywood is extremely resistant to wear and tear

Safety handles

Note:

Do not access, get on the formwork or use the safety handles until the panels have been properly braced.



A Integral safety handle

- and are used to tie off safety harnesses.



Warning!

Do not use the safety handles as slinging points for crane-handling!

Danger of formwork dropping from crane!

- ▶ Use only suitable load-carrying equipment and slinging points. See "Resetting by crane" and "Transporting, stacking and storing".


Nail-holes

- are integrated in the frame profile to make it easier to attach or nail the panel to the ground or sills
- the nail-holes are located all around the frame, so the panels can be arranged either vertically or horizontally





The logical system-grid

Framed formwork panels

Widths of panels



Heights of panels



Dimensions in inch

Dimensions in cm

For pour heights of up to 9'-0" (2.74 m) only **2 form-ties** needed in the vertical.


Universal panels

The **3'-0" wide** panels are also available as **Universal panels** with heights of 2'-0", 3'-0", 4'-0", 6'-0" and 9'-0".


The special hole pattern makes these panels particularly suitable for efficient forming of:

- corners
- wall junctions
- bulkheads
- columns


Panel width



Heights of panels



Dimensions in inch




Dimensions in cm

Adaptability

Possible combinations


The perfect panel size-grid gives you innumerable possible combinations, in both width and height. You can use the panels either **vertical** or **horizontal**, and the **6" (15 cm) increment-grid** gives you optimum adaptability of the formwork to the dimensions of the structure, at all times.



Schematic representation

Infinite height offset


The continuous hardware slot around the inside of the Frami panels enables the clamps to be fastened anywhere on the frame. This allows any adjacent panels to be **staggered to any height required**, i.e. without being confined to any fixed grid. This means that the formwork can easily be accommodated to e.g. steps, slopes and uneven ground, with no extra work.



Schematic representation


Continue forming with job-built fillers

The framed formwork Frami also gives you easy connections when you need to "make up" with job-built timber formwork. The Frami universal waling and filler angle make it easy for you to join the panels to dimensional lumber and plywood.




- A** Frami universal waling
- B** Frami wedge clamp
- C** Frami S filler angle 3/4"
- D** Frami clip
- E** Dimensional lumber
- F** Formwork sheet
- G** Frami S panel

Joining gangs



Simple inter-panel connections

with the Frami clamp



Frami clamp:

Permitted tensile force: 2.245 kip (10.0 kN)

Permitted shear force: 1.12 kip (5.0 kN)

Permitted moment: 0.15 kip-ft (0.20 kNm)

The continuous hardware slot running around the inside of the frame profile means that panels can be fastened together anywhere on the frame. This allows adjacent panels to be staggered in height, infinitely.

The Frami clamp and the Frami adjustable clamp


- create fast, self-aligning and tension-proof joints
- have no loose parts which might get lost
- are hard-wearing and dirt-resistant for site use
- should only be fixed using a formwork hammer (max. 28 oz. / 800 g)


Upright panels:


Panel height	Number of clamps
3'-0"	2
4'-0"	2
6'-0"	2
9'-0"	3



Horizontal panels:

Panel width	Number of clamps
6"	1
1'-0"	1
1'-6"	1
2'-0"	2
2'-6"	2
3'-0"	2

 For details regarding extra inter-panel connections for outside corners and bulkheads (for increased tensile loads): see "Inter-panel connections for increased tensile loads".


 For details on the position of the connector components needed in vertical stacking, see "Vertical stacking of panels".

 **Important note:**
Do not oil or grease wedge-clamped joints.



Self-aligning inter-panel connections and fillers


with the Frami adjustable clamp




Frami adjustable clamp:

Permitted tensile force: 1.685 kip (7.5 kN)

Filler gaps can be closed easily and economically with Frami S steel fillers. With the Frami adjustable clamp, the panels are joined so that they are resistant to tensile forces, and are aligned at the same time. The adjustable clamp is placed directly over the cross profile.




a ... max. 6" (15 cm)




In cases where the Frami adjustable clamp would collide with steel fillers, universal walings, etc., it must be located next to the cross profile (instead of directly over it).


Formwork height: 9'-0" (2.74 m)




Formwork height: 6'-0" (1.82 m)



Formwork height: 4'-0" (1.22 m)




Formwork height: 3'-0" (0.91 m)



Form-tie system

Tying the Frami panels



Tying the Frami 9'-0" panels:

Up to a pour height of 9'-0" (2.74 m) (with no vertically stacked panels), **only 2 form-ties** are required in the vertical.


Apart from this, the basic rule here is:

Place a form-tie in every form tie hole within a panel that is not covered by a tie washer (e.g. at a panel joint, only tie one of the two adjoining panels).

Always tie in the bigger (wider) of the two panels.

For exceptions, see "Length adjustment using fillers" and "Vertical stacking of panels".

Form-tie situations



- Only use approved tie-rods.
- Never weld or heat tie-rods.



Close off any unneeded tie-holes with Frami S frame-hole plugs


Note:

Doka also offers economical solutions for creating watertight wall-ties.



For more information, see the User Information booklet "Doka form-ties for special requirements".

Taper-tie system 3/4" to 1"



A Super-plate 15.0

B Taper tie 3/4" to 1" & 5/8" [15.0] ends

For forming wall thicknesses in the 6" to 30" (15.2 to 76.2 cm) range, there are 4 different types of taper tie:

Wall thickness:	Form-tie length
6" to 12" (15.2 to 30.5 cm)	32"
12" to 18" (30.5 to 45.7 cm)	38"
18" to 24" (45.7 to 61.0 cm)	44"
24" to 30" (61.0 to 76.2 cm)	52"


Note:

Always loosen the Super-plate on the thinner end of the taper tie first.

Taper tie 3/4" to 1" & 5/8" [15.0] ends:

Permitted capacity allowing a 2 : 1 factor of safety against failure: 18,000 lbs (80 kN)

She-bolt system 7/8"




- A** She-bolt 7/8"x19"
- B** Super-plate 20.0 B
- C** Tie-rod 15.0mm (length = wall thickness - 4" (10 cm))

She-bolt system 7/8":


Permitted capacity allowing a 2 : 1 factor of safety against failure: 18,000 lbs (80 kN)

Form-tie system 15.0 (5/8"Ø)

The Form-tie system 15.0 makes it possible to tie panels in narrow or confined spaces. For areas of application, see "Acute and obtuse-angled corners".



- A** Super-plate 15.0
- B** Tie-rod 15.0mm
- C** Plastic tube 22mm
- D** Universal cone 22mm

 The "Plastic tubes 22mm" left behind in the concrete are sealed off with "**Plugs 22mm**".



Spanner for tie-rod 15.0/20.0


For turning and holding the tie-rods.




Tie-rod 15.0mm:

Permitted capacity, allowing a 2 : 1 factor of safety: 22,000 lbs (98 kN)

Sloping ties on height-mismatched panels

Thanks to the special shape of the Super-plate, the panels can be inclined on one or both sides, and/or height-mismatched.




Inclined on one side	Inclined on both sides	Height mismatch
max. 4°	max. 2 x 4°	Form-tie system 15.0: max. 1/2" per 6" wall thickness (1.2 cm per 15 cm) Taper tie 3/4" to 1" & 5/8" [15.0] ends: max. 1/4" per 6" wall thickness (0.6 cm per 15 cm)
		
9777-356-01	9777-355-01	9777-359-01


Note:

Secure inclined panels against uplift.

Form-tie situations



Stack max. 3'-0" on top of one 6'-0" high basic panel!




Length adjustment using fillers

Filler gaps: 1" - 6" (2.5 - 15 cm)

with steel fillers and adjustable clamps

By combining the steel filler widths of 1", 1 1/2", and 2" in various ways, the closures can be made in 1/2" (13 mm) increments.



- A** Frami S steel filler 2" (with through-tie facility)
- B** Frami S steel filler 1 1/2"
- C** Frami S steel filler 1"
- D** Frami clip
- E** Frami S framed panel

In order to get a firm link between the filler and the panels, fix the steel fillers in place with Frami clips (D).

Note:


Form ties can be placed through the 2" (5 cm) wide Frami S steel filler. The steel filler through which the tie is being placed must be fitted in a central position.

Up to 3" (7,6 cm) filler width	Up to 6" (15 cm) filler width
Place form-ties in panel, with universal waling	Place form-ties in filler, with universal waling

We also offer a number of other solutions for filler widths of 2", 3", and 6" (5, 7.6 and 15 cm).

Any unneeded tie-holes in the steel filler should be closed off with **Frami plugs**.

Frami universal waling:
Permitted moment: 0.96 kip-ft (1.3 kNm)



Note:

Where form-ties are inserted through the panel frames, the Universal waling must rest on the cross profile.

Tying through the panel

<p>(A) Universal waling in the horizontal (over the cross profile)</p>	<p>(B) Universal waling at an angle (so that it rests on the cross profile)</p>
---	--

Tying through the filler


Universal waling in the horizontal

--	--


Vertical stacking with fillers

Due to the space constraints encountered here, the Universal waling is generally positioned on the panel joint at an angle.

Formwork height: 15'-0" (4.57 m)




Formwork height: 12'-0" (3.66 m)




Tying at the panel joint (through the panel)

(C) Universal waling at an angle




Tying at the panel joint (through the filler)

(D) Universal waling at an angle



Filler width 1" (2.5 cm)


Place form-ties in panel, with universal waling



1 Frami S steel filler 1"

Filler width 2" (5.1 cm)


Place form-ties in filler, without universal waling.



1 Frami S steel filler 2"

Filler width 1 1/2" (3.8 cm)


Place form-ties in panel, with universal waling



1 Frami S steel filler 1 1/2"

Filler width 2 1/2" (6.4 cm)


Place form-ties in panel, with universal waling



1 Frami S steel filler 1"
1 Frami S steel filler 1 1/2"

Filler width 2" (5.1 cm)


Place form-ties in panel, with universal waling



2 Frami S steel fillers 1"

Filler width 3" (7.6 cm)


Place form-ties in panel, with universal waling



2 Frami S steel fillers 1 1/2"

Filler width 3" (7.6 cm)


Place form-ties in filler, with universal waling



- 1 Frami S steel filler 1"
- 1 Frami S steel filler 2"

Filler width 4 1/2" (11.4 cm)


Place form-ties in filler, with universal waling



- 1 Frami S steel filler 1"
- 1 Frami S steel filler 1 1/2"
- 1 Frami S steel filler 2"

Filler width 3 1/2" (8.9 cm)


Place form-ties in filler, with universal waling



- 1 Frami S steel filler 1 1/2"
- 1 Frami S steel filler 2"

Filler width 5" (12.7 cm)


Place form-ties in filler, with universal waling



- 2 Frami S steel fillers 1 1/2"
- 1 Frami S steel filler 2"

Filler width 4" (10.2 cm)


Place form-ties in filler, with universal waling



- 2 Frami S steel fillers 2"

Filler width 5 1/2" (14 cm)

Place form-ties in filler, with universal waling




- 1 Frami S steel filler 1 1/2"
- 2 Frami S steel fillers 2"

- A** Frami adjustable clamp
- B** Frami S steel filler
- C** Frami universal waling
- D** Form-tie

Filler width: 6" (15.2 cm)


Place form-ties in filler, with universal waling



3 Frami S steel fillers 2"

- A** Frami adjustable clamp
- B** Frami S steel filler
- C** Frami universal waling
- D** Form-tie

A combination of three Frami S steel fillers 2" is used if it is necessary to tie through a 6" (15 cm) filler.





a ... 14" (35.5 cm)
b ... 12" (30.5 cm)

- A** Frami S inside corner
- B** Frami S outside corner
- C** Frami clamp
- D** Frami adjustable clamp
- E** Frami universal waling
- F** Frami S steel filler
- G** Frami S panel 2'-0"
- H** Frami S panel 2'-0"

Filler width: 6" (15.2 cm)

with 6" framed panel



- A** Frami clamp
- B** Frami S panel 6"x9'-0"
- C** Form-tie

using filler angles and plywood

Required numbers of Frami clips:



Frami S filler angle 3/4"	N° of units
3'-0"	2
4'-0"	2
6'-0"	3
9'-0"	4



Important note:

Where tensile loads occur (on corners and bulkheads), suitable tension anchoring must be provided.



Filler width: 4" - 10" (10.2 - 25.4 cm)



a ... 4" to 10" (10.2 to 25.4 cm)

- A Frami S filler angle
- B Frami clip
- C Plywood 3/4"
- E Frami universal waling 1.25 m
- F Frami wedge clamp
- G Form-tie

Filler width: > 10" - 20" (> 25.4 - 50.8 cm)



a ... > 10" to 20" (> 25.4 to 50.8 cm)

- A Frami S filler angle
- B Frami clip
- C Plywood 3/4"
- D Dimensional lumber 2 3/4"
- E Frami universal waling 0.70m and 1.25m
- F Frami wedge clamp
- G Form-tie



Possible ways of attaching Universal walings:

For accessories with an **overall height of 2" (5 cm)**
(Frami universal waling **(E)**):

- Frami wedge clamps **(F)**



For accessories with an **overall height of 2" to 4"**
(5 cm to 10 cm) (e.g. Framax S universal waling **(H)**):

- Frami universal fixing bolt **(I)** + Super-plate **(J)**



90 degree corners

The corner solutions are based on the strong, torsion-proof **Frami inside corner**.



a ... 12" (30.5 cm)

There are **2 ways** of forming right-angled **outside corners**:


- with a Frami universal panel
- with a Frami outside corner



For details regarding extra clamps on outside corners (for increased tensile loads) see "Inter-panel connections for increased tensile loads".

with a Frami outside corner


The Frami outside corner is an easy and problem-free way of forming corners in narrow trench situations or where large wall thicknesses are called for.



Required numbers of Frami clamps and Frami clip:

	Up to a wall thickness of		
	16" (41 cm)	24" (61 cm)	30" (76 cm)
Outside corner 3'-0"	4	4	4
Outside corner 4'-0"	6	6	6
Outside corner 6'-0"	6	8	8 + 4 ¹⁾
Outside corner 9'-0"	10	12	12 + 4 ¹⁾

¹⁾ Number of Frami clips




a ... 16" (40.6 cm)

b ... 12" (30.5 cm)

- A Frami S inside corner
- B Frami S outside corner
- C Frami clamp
- D Frami adjustable clamp
- E Frami universal waling
- F Frami S steel filler
- G Frami S panel 2'-0"
- H Frami S panel 2'-0"


Example with a wall thickness of 28" (71 cm)



a ... 28" (71 cm)

- A** Frami S inside corner
- B** Frami S outside corner
- C** Frami clamp + Frami clip
- D** Frami adjustable clamp
- E** Frami universal waling
- F** Frami S steel filler
- G** Frami S panel 3'-0"
- H** Frami S panel (max. 2'-0")

Example with a wall thickness of 30" (76 cm)





a ... 30" (76 cm)

- A** Frami S inside corner
- B** Frami S outside corner
- C** Frami clamp + Frami clip
- D** Frami universal waling
- E** Framax S universal waling
- F** Frami S panel 3'-0"
- G** Frami S panel 6"
- H** Frami S panel (max. 2'-0")

with a Frami universal panel

When this panel is used, a wall-thickness grid with 2" (5.1 cm) increments is available.




a ... 12" (30.5 cm)
b ... 16" (40.6 cm)

- A** Frami S inside corner
- B** Frami S universal panel
- C** Frami universal fixing bolt + Super-plate 15.0
- D** Frami clamp
- E** Frami S panel 2'-0"

Note:

When steel fillers are used, it is also possible to handle wall thicknesses of up to 24" (61 cm).

Attainable wall thicknesses in a 2" (5.1 cm) increment-grid:




Required numbers of Frami universal fixing bolts + Super-plates 15.0:

Universal panel 3'-0"x3'-0"	2
Universal panel 3'-0"x4'-0"	3
Universal panel 3'-0"x6'-0"	4
Universal panel 3'-0"x9'-0"	6

Chamfer Edges


with triangular chamfer




- A** Frami S outside corner
- B** Frami clamp
- C** Frami S panel
- D** Triangular chamfer
- E** Wire nail

Triangular chamfers can also be used on corners formed using the Universal panel.

T-junction with Frami inside corner



Wall thicknesses up to 20" (50.8 cm)



a ... 12" (30.5 cm)


A Frami S inside corner

B Frami clamp

C Frami S panel 3'-0"

Where 4" steel fillers are used on both sides, wall thicknesses of up to 20" (50.8 cm) can be formed.

Wall thicknesses up to 30" (76.2 cm)



a ... 30" (76.2 cm)

A Frami S inside corner

B Frami clamp

C Frami S panel 3'-0"


D Frami S panel 1'-6"

E Multi-purpose waling WS10 Top50 6'-0"

F Frami universal waling

Pilasters

Pilasters can be formed quickly using pilaster panels.




a ... 24" (61 cm)

b ... 6" (15.2 cm)

The pilaster panel permits pilaster depths of up to 20" (51 cm) in 2" (5.1 cm) increments, and of 24" (61 cm) when outside corners are used.

2 positions / functions:


- bolted in place at right-angles → for pouring



c ... max. 24" (61 cm)

d ... 8" - 20" (20.3 - 51 cm)

- folded closed → for stripping and resetting the formwork



A Frami S pilaster panel

B Frami universal fixing bolt 5-12cm

C Super-plate 15.0

D Frami S panel

E Frami S panel > 6" (without filler)

Required number of connectors per pilaster:

Panel height	Universal fixing bolts + Super-plates 15.0
3'-0"	4
4'-0"	4
6'-0"	6
9'-0"	8




To ensure that the formwork can be lifted safely, bolt the pilaster panel in the "folded closed" position.



T-junction with Frami pilaster panel


Wall thicknesses from 26" to 28" (66 to 71 cm)



a ... 26" to 28" (66 to 71 cm)

- A** Frami S pilaster panel
- B** Frami S panel 3'-0"
- C** Frami S steel filler
- D** Frami adjustable clamp
- E** Frami universal waling

Wall thicknesses up to 30" (76.2 cm)




a ... 30" (76.2 cm)

- A** Frami S pilaster panel
- B** Frami S panel 3'-0"
- C** Frami S panel 6"
- D** Frami clamp
- E** Multi-purpose waling WS10 Top50 6'-0"

Acute and obtuse-angled corners

Frami also has the perfect solution ready for acute and obtuse-angled corners - the Frami hinged corners.



When preparing the corners, remember the following points:

With angles of 120° and upward, Universal walings must be used on the inside corner (at every support level of the hinged corner).

On outside corners, Universal walings should generally be positioned (4 Universal walings per 9'-0" (2.74 m) pour height).

If there are fillers, fit extra Universal walings as shown in "Length adjustment using fillers".

For details regarding extra clamps on outside corners (for increased tensile loads) see "Inter-panel connections for increased tensile loads".



Number of Frami clamps needed in the whole hinged outside corner (i.e. for both sides):

Panel height	Width of panel next to hinged outside corner	
	up to 2'-0"	up to 3'-0"
3'-0"	4	4
4'-0"	4	6
6'-0"	6	8
9'-0"	8	12


Note:

Acute-angled (pointed) corners are tied using the Form-tie system 15.0 (5/8"Ø). This makes it possible to form angles of as little as 60°.


60° - 135° angles, with hinged corners I + A




- A Frami S hinged outside corner A
- B Frami S hinged inside corner I
- C Frami S panel
- D Frami clamp
- E Frami universal waling 1.25m
- F Frami wedge clamp
- G Form-tie



135° - 180° angles, with hinged inside corner I only



- A** Frami S hinged inside corner I
- B** Frami clamp
- C** Frami universal waling
- D** Frami wedge clamp
- E** Form-tie
- F** Frami S panel



- A** Frami S hinged outside corner A
- B** Frami S hinged inside corner I
- C** Frami S panel
- D** Frami clamp
- E** Frami universal waling
- F** Frami wedge clamp
- G** Form-tie



Shaft formwork

Shaft formwork with Bias-cut corner I

With the **Bias-cut corner I**, the entire shaft formwork unit is detached from the wall, in one piece, before being lifted and reset by crane.



Product features:

- No negative impression in the concrete.
- Formwork set-up and stripping function integrated in the inside corner (no need for crane – uses stripping spindles).
- Entire shaft formwork unit is lifted and reset in one piece (with lifting hooks and four-part lifting chain).



a ... 12" (30 cm)

Stripping play:



a ... 1 1/8" (30 mm)
b ... 2 1/4" (60 mm)


- A Framax S bias cut corner I
- B Framax stripping spindle I with ratchet
- C Steel form-facing

Position of fillers (fitting-timbers) in the inside shaft formwork:

- as close as possible to the middle of the formwork
- not directly next to the bias-cut corners

Joining gangs

The Framax bias-cut corner I is joined onto the Frami panels by means of **Framax quick-acting clamps RU**. The **difference in thickness between the profiles** is bridged here by the **Frami profile adapter**.




D Frami profile adapter for Bias-cut corner I

E Framax quick-acting clamp RU

Number of Framax quick-acting clamps RU needed:


Height of Bias-cut corner I	Panel height	Number of clamps
1.35 m	3'-0"	4
1.35 m	4'-0"	4
2.70 m	6'-0"	6
2.70 m	9'-0"	6

 In order to obtain the full available stripping-play, make sure that the Framax quick-acting clamps RU are mounted at staggered heights (i.e. not opposite one another).

Tying the panels

When tying the shaft formwork, the **tie-hole positions of the Frami panels** should be used.


The **difference in thickness between the profiles** is bridged here by the **Frami tie-adapter**.



F Frami tie-adapter for Bias-cut corner I

Vertical stacking of Framax bias-cut corners I

- 1) Pull out the coupling bolt.
- 2) Maneuver the Bias-cut corner I into place so that it is flush with the one below it.
- 3) Push the coupling bolt back in.
- 4) Bolt the Bias cut corners I together with two hexagonal bolts.




A Coupling bolt

B Bias-cut corner I

C Hexagonal bolt M16x45 (or $\frac{5}{8} \times 1 \frac{3}{4}$ ")

Mounting the Framax stripping spindle I

- 1) Pull out the U-bolt from the stripping spindle.
- 2) Place the stripping spindle on the centering stud of the bias-cut corner.
- 3) Twist the stripping spindle clockwise until fully engaged.
- 4) Position the ratchet between the holes in the push-rod.
- 5) Fix the stripping spindle with the U-bolt.



A Framax stripping spindle I with ratchet

B U-bolt


C Centering stud of bias-cut corner

D Ratchet

E Push-rod

Operating the Framax stripping spindle I with ratchet


- Screw a Tie-rod 15.0mm into the Weldable coupler 15.0 of the ratchet.
- **Setting up:**
 - shift the change-over lever into the "L" position
 - turn the ratchet **clockwise**.
- **Stripping:**
 - shift the change-over lever into the "R" position
 - turn the ratchet **anti-clockwise**.



- A Tie-rod 15.0mm
- B Weldable coupler 15.0
- C Ratchet
- D Change-over lever




You can also use a **formwork hammer** to operate the ratchet, instead of a Tie-rod 15.0mm.



Resetting by crane

Resetting by crane:



$\beta \dots \text{max. } 15^\circ$

- A Frami lifting hook
- B Four-part lifting chain (e.g. Doka 4-part chain 3.20m)



The crane hook on the Bias-cut corner I is not allowed to be used for lifting the shaft formwork.


- The shaft formwork may **only be reset using lifting hooks**.

Permitted weight of the shaft formwork:
4400 lbs (2000 kg) with 4 Frami lifting hooks

Doka shaft platform

With its telescopic shaft beams, this platform can accommodate any dimension of structure. The inside formwork can be "parked" on the platform and repositioned together with the platform.

The Frami panel shoe provides increased stability on shaft platforms.



- E Frami panel shoe



Follow the directions in the "Doka shaft platform" User Information booklet.


Inter-panel connections for increased tensile loads

As a basic rule, only **3 clamps** are needed per **9'-0" panel height**, and **2 clamps** per **6'-0"**, **4'-0"** and **3'-0" panel height**, as tension links between the panels.

However, where **increased tensile loads** need to be sustained, especially near outside corners and bulkheads, **extra clamps** are needed.

Near bulkheads


for wall thicknesses from 16" to 24" (40 to 61 cm)



a ... 16" to 24" (40 to 61 cm)

Panel height	Number of clamps
	In zone "X1" (panel joints within 6'-0" (1.8 m) of a bulkhead)
9'-0"	3 + 1
6'-0"	2 + 1
4'-0"	2
3'-0"	2

for wall thicknesses of over 24" and up to 30" (61 cm and up to 76 cm)





a ... up to 30" (76 cm)

Panel height	Number of clamps
	In zone "X1" (panel joints up to 6'-0" (1.8 m) away from a bulkhead)
9'-0"	3 + 2
6'-0"	2 + 1
4'-0"	2
3'-0"	2

Near outside corners



for panel widths up to 2'-0"



e ... up to 2'-0" (panel width)

Panel height	Number of clamps	
	In zone "X1" (panel joints within 6'-0" (1.8 m) of an outside corner)	
9'-0"	3 + 1	
6'-0"	2 + 1	
4'-0"	2	
3'-0"	2	


for panel widths over 2'-0" and up to 3'-0"



e ... > 2'-0" up to 3'-0" (panel width)

Panel height	Number of clamps	
	In zone "X1" (panel joints within 6'-0" (1.8 m) of an outside corner)	In zone "X2" (panel joints 6'-0" to 10'-0" (1.8 to 3.0 m) from an outside corner)
9'-0"	3 + 3	3 + 1
6'-0"	2 + 2	2 + 1
4'-0"	2 + 1	2
3'-0"	2	2

for panel widths of over 3'-0" and up to 3'-6"



e ... > 3'-0" up to 3'-6" (panel width)

Panel height	Number of clamps	
	In zone "X1" (panel joints up to 6'-0" (1.8 m) away from an outside corner)	In zone "X2" (panel joints between 6'-0" and 10'-0" (1.8 to 3.0 m) away from an outside corner)
9'-0"	3 + 3	3 + 2
6'-0"	2 + 2	2 + 1
4'-0"	2 + 1	2
3'-0"	2	2


Bulkhead formwork

There are **3 possible ways** of forming bulkheads:

- with Universal panels
- with Universal walings
- with outside corners

with Universal walings

The Universal waling makes it possible to form bulkheads continuously across any thickness of wall. The Universal walings are mounted using Universal fixing bolts 5-12cm and Super-plates 15.0.



Frami universal fixing bolt:

Permitted tensile load:

- 2.92 kip (13.0 kN), when used in a standard panel
- 3.51 kip (15.6 kN), when used in a Universal panel


Frami universal waling:

Permitted moment: 0.96 kip-ft (1.3 kNm)

Framax S universal waling:

Permitted moment: 3.85 kip-ft (5.2 kNm)

For details regarding extra clamps on bulkheads (for increased tensile loads) see "Inter-panel connections for increased tensile loads".





- A Frami universal waling or Framax S universal waling
- B Universal fixing bolt 5-12cm
- C Super-plate 15.0
- D Frami S panel > 6"
- E Form-tie

Positioning the Universal walings where the formwork height is 9'-0" (2.74 m):

Walls up to 16" (40 cm) thick	Walls up to 24" (61 cm) thick	Walls up to 28" (71 cm) thick	Walls up to 30" (76 cm) thick
3 Frami universal walings	5 Frami universal walings	4 Framax S universal walings	5 Framax S universal walings
 9777-394-01	 9777-395-01	 9777-389-01	 9777-388-01

with Universal panels

The continuous hole grid on the Universal panels makes it possible to form bulkheads in 2" (5.1 cm) increments.



- A** Frami S universal panel
- B** Frami universal fixing bolt 5-12cm
- C** Super-plate 15.0
- D** Frami S outside corne
- E** Frami clamp
- F** Frami S panel



Required numbers of connectors:

Panel height	Universal fixing bolt + Super-plate	Frami clamp
3'-0"	2	4
4'-0"	2	4
6'-0"	3	6
9'-0"	4	8

The values given here apply up to a wall thickness of 24" (61 cm).

with standard panel

For walls whose thickness corresponds exactly to the panel width.



- A** Frami S panel
- B** Frami S outside corner
- C** Frami clamp

Required numbers of Frami clamps per bulkhead:


Panel height	Frami clamp
3'-0"	8
4'-0"	8
6'-0"	12
9'-0"	16

The values given here apply up to a wall thickness of 24" (61 cm).

Wall junctions


Right-angled connections

with Universal panels



- A** Frami S universal panel
- B** Tie-rod 15.0 (on the Universal panel 9'-0", 3 form-ties are required)
- C** In-place timber brace


with standard panels and dimensional lumber:



- A** Frami S panel
- B** Dimensional lumber, max. 4" (10 cm)
- C** Universal waling (not needed where the dimensional lumber is up to 2" (5 cm) wide)
- D** Frami wedge clamp
- E** Form-tie
- F** In-place timber brace

In-line connections


with Universal panels



- A** Frami S universal panel
- B** Tie-rod 15.0


Form-tie position X	Number of form-ties in the Universal panel 9'-0"
up to 6" (15 cm)	4
up to max. 10" (25 cm)	6

with standard panels and dimensional lumber:



- X ... max. 2" (5 cm)
- A** Frami S panel
 - B** Dimensional lumber
 - C** Adjustable clamp
 - D** Form-tie


with a standard panel from the previous casting section:




- A** Frami S panel
- B** Form-tie

Corner connections

with standard panels and dimensional lumber:



- A** Frami S panel
- B** Dimensional lumber, max. 4" (10 cm)
- C** Frami S panel 6"
- D** Universal walings (not needed where the dimensional lumber is up to 2" (5 cm) wide)
- E** Frami wedge clamp
- F** Frami clamp
- G** Form-tie
- H** In-place timber brace




- A** Frami S panel
- B** Dimensional lumber, max. 2" (5 cm)
- C** Dimensional lumber
- D** Adjustable clamp
- E** Form-tie
- F** In-place timber brace

Vertical stacking of panels

Positions of the interconnecting and form-tie components and accessories needed for:

- lifting and setting down
- crane-handling
- platform loads
- pouring

 Follow the directions in the section headed "Form-tie system".

Note:


When panels are vertically stacked, the arrows point upward.

Frami clamp:

- Permitted tensile force: 2.245 kip (10.0 kN)
- Permitted shear force: 1.12 kip (5.0 kN)
- Permitted moment: 0.15 kip-ft (0.20 kNm)


Frami universal waling:

- Permitted moment: 0.96 kip-ft (1.3 kNm)




- A Tie-rod + Super-plate 15.0
- B Frami clamp
- C Frami wedge clamp
- D Frami universal waling 1.25m

Important note:

 Do not oil or grease wedge-clamped joints.


Formwork height:

6'-0" to 8'-0" (183 to 244 cm)



Formwork height:


7'-6" to 9'-0" (228 to 274 cm)



Stack max. 3'-0" on top of one 6'-0" high basic panel!


Formwork height:

8'-6" and 9'-0" (259 and 274 cm)




Formwork height:


9'-6" and 10'-0" (289 and 305 cm)



**Formwork height:
10'-0" (305 cm)**




**Formwork height:
12'-0" (365 cm)**




- A Framax S universal waling 1.50m
- B Frami profile connector 5-18cm + Super plate 15.0


**Formwork height:
10'-6" to 12'-0" (320 to 365 cm)**




**Formwork height:
12'-6" and 13'-0" (381 and 396 cm)**




**Formwork height:
12'-0" (365 cm)**




**Formwork height:
13'-0" (396 cm)**




**Formwork height:
13'-6" to 15'-0" (411 to 457 cm)**




**Formwork height:
15'-0" (457 cm)**




**Formwork height:
14'-6" and 15'-0" (442 and 457 cm)**




**Formwork height:
15'-6" and 16'-0" (472 and 487 cm)**




**Formwork height:
15'-6" and 16'-0" (472 and 487 cm)**




**Formwork height:
16'-6" to 18'-0" (503 to 548 cm)**



**Formwork height:
16'-6" to 18'-0" (503 to 548 cm)**




**Formwork height:
18'-0" (548 cm)**



Note:

When adding narrow gangs, observe the following rules for vertical stacking of panels:




The illustrations given here show the most economical solutions for each formwork height.

Other combinations require correspondingly more connector components.

Notes

A large grid of graph paper for taking notes, consisting of 30 columns and 40 rows of small squares.

Plumbing accessories



Note:
Every gang-form must be supported by **at least 2 panel struts**.



For more information (wind loads etc.) see the section headed "Vertical and horizontal loads" in the Doka Calculation Guide.

Fixing to the floor

➤ Anchor the plumbing accessories in such a way as to resist tensile and compressive forces!


Boreholes in the footplates

Plumbing strut 260	Struts 340 / 540	Pipe brace 12'-0"-21'-0"
 9723-288-01	 9727-343-01	 9762-358-01

- a ... 1"Ø (26 mm)
- b ... 1 1/16"Ø (18 mm)
- c ... 1 1/16"Ø (27 mm)
- d ... 1 3/16"Ø (20 mm)

Anchoring the footplate

The **Doka Express anchor** can be re-used many times over - the only tool needed for screwing it in is a centering fork-wrench or a rebar.



- A** Doka Express anchor 16x125mm
- B** Doka coil 16mm

Cylinder compressive strength of concrete:
min. 3000 psi (20 N/mm²)



Follow the Fitting Instructions!

Required safe working load of alternative anchor for foot-plates: min. 3.0 kip (13.5 kN)
Follow the manufacturer's applicable fitting instructions.

The Frami plumbing strut 260, Struts 340 / 540, and the Pipe brace 12'-0"-21'-0", ensure that the formwork remains stable against wind loads, and make it easier to plumb and align the formwork.



Important note:

The formwork gangs must be securely braced in **every** phase of the construction work!
Observe all applicable safety rules!



Caution!

There is a risk of the formwork tipping over in **high winds**.

➤ If high wind speeds are likely, and when work finishes for the day or before prolonged work-breaks, always take extra precautions to fix the formwork in place.

Suitable precautions:

- set up the opposing formwork
- place the formwork against a wall
- anchor the formwork to the ground

Permitted spacing of the struts:

Formwork height	Plumbing struts 260	Struts 340*	Struts 540 / Pipe brace 12'-0"-21'-0"*
6'-0" (1.83 m)	9'-0" (2.75 m)		
9'-0" (2.75 m)	4'-6" (1.37 m)		
12'-0" (3.66 m)		12'-0" (3.66 m)	
15'-0" (4.57 m)			12'-0" (3.66 m)
18'-0" (5.48 m)			9'-0" (2.75 m)
Max. anchoring load: 3.0 kip (13.5 kN)			

Values apply up to a wind pressure of 15 psf (0.72 kN/m²). In cases where higher wind pressure is encountered, the number of props must be determined by statical calculation.

* in conjunction with the Frami S bracing head or the Frami S connection profile.

The rule-of-thumb here is:


The length of the struts or pipe-braces should be the same as the height of the panel to be supported.

- ▶ Use the nail-holes to fasten the panels to the ground or sills.


Plumbing strut 260

Fixing the struts to the formwork

- ▶ Fix the Plumbing strut into the cross boreholes in the cross profiles (frame profiles) with a pin.




9714-278-01



9777-383-01

a ... min. 4'-9" - max. 8'-6" (min. 145 - max. 258 cm)


Strut 340



9777-204-02

a ... min. 6'-4" - max. 11'-2" (min. 193 - max. 340 cm)


Strut 540



9777-321-01

a ... min. 10'-2" - max. 18'-0" (min. 310 - max. 548 cm)

Pipe brace 12'-0"-21'-0"



9777-342-01

a ... min. 12'-0" - max. 21'-0" (min. 366 - max. 640 cm)


Fixing the struts to the formwork

with Frami S bracing head

The Frami S bracing head allows bracing to be attached to the frame profile.


Fixing the Frami S bracing head to Struts 340 / 540 (A)

- Attach the Frami S bracing head to the strut with the included bolt and spring cotter.



Fixing the Frami S bracing head to the Pipe brace 12'-0"-21'-0" (B)


- Attach the Frami S bracing head to the pipe brace using a speed bolt and speed nut.




- A Strut 340 / 540
- B Pipe brace 12'-0"-21'-0"
- C Speed bolt 3/4"x4"
- D Speed nut 3/4"

Attaching the Frami S bracing head to the frame profile


- 1) Place the bracing head onto an empty cross profile.
- 2) Slide the bracing head until it is flush with the frame profile.
The stud-pins will slide into the cross boreholes of the frame profiles.
- 3) Push the U-bolt to secure the head in place.




Possible connection points on upright or horizontal framed panels



On upright framed panels



On horizontal framed panels




with Frami S connection profile

This connection method is used on column formwork, circular formwork and wherever it is not possible to attach the Frami S bracing head to the frame profile.


The Frami S connection profile is suitable for both Frami standard and universal panels.

- Use Frami wedge clamps to fasten the Frami S connection profile in the cross boreholes of the **cross-profiles or frame profiles**.


On framed panels



On universal panels



On the panel joint (stacked horizontally)




A Frami S connection profile
B Frami wedge clamp

Attaching the struts to the Frami S connection profile


On the Frami S connection profile there are connection points for the Pipe brace 12'-0"-21'-0" and for the Struts 340 / 540.

- Guide the Pipe brace 12'-0"-21'-0" to the relevant connection point and fix it in place with a speed bolt and speed nut.
- If using Struts 340 / 540, attach the Frami S connection profile with a bolt and a spring cotter.



A Frami S connection profile
B Strut 340 / 540
C Pipe brace 12'-0"-21'-0"

Pouring platforms with single brackets



The Frami brackets 60 enable you to assemble pouring platforms that can easily be mounted by hand.

Preconditions for use:

Only fix the pouring platform onto formwork constructions that are sufficiently stable to transfer the expected loads.

Also brace the formwork in a windproof manner when erecting it and when it is temporarily "parked" in the standing position.

Ensure that the formwork gang has sufficient stiffness.

Observe all applicable safety rules.

with Frami bracket 60

The Frami bracket 60 is a "use-anywhere" bracket for making pouring platforms (platform width 2'-0" (60 cm)).

Note:

The scaffold planks and guard-rail material shall meet or exceed any local, state, provincial or national regulations.

Plank thicknesses for support centers of up to 6'-6" (2.00 m):

- 2 scaffold planks 2 x 10, min. 1 1/2 x 9 1/2" (4 x 24 cm)
- 1 scaffold plank 2 x 6, min. 1 1/2 x 5 1/2" (4 x 14 cm)
- 2 guard-rail planks 2 x 4, min. 1 1/2 x 3 1/2" (4 x 9 cm)
- 1 guard-rail plank 2 x 6, min. 1 1/2 x 5 1/2" (4 x 14 cm) (toe-board)

Fastening the scaffold planks:

with 3 carriage bolts 3/8-16 x 4 3/4 (cup square screws M 10x120) per bracket (not included with product).

Fastening the guard-rail boards: Use nails

Permitted service load: 25 psf (120 kg/m²)

Max. influence width: 6'-0" (1.80 m)


Complies with the following Standards:

- OSHA 1926, Subpart L
- CAN/CSA S269.2 - "Access Scaffolding for Construction Purposes" (light-duty scaffolds)

The brackets must be secured against accidental lift-out

Multi-panel gangs without an opposing formwork and with pouring platforms must be fixed on the ground so as to prevent slippage.

On upright panel (fixed in the cross profile)



h ... 3'-7" (110 cm)

A Frami bracket 60


B Upright panel

C Spring cotter (protection against accidental lift-out)

Note:


The bracket must NOT be fixed in the circular hole in the middle of the cross profile.

On horizontal panel (fixed in the cross profile)



- A** Frami bracket 60
- B** Horizontal panel
- D** Fastening pin with linch pin (protection against accidental lift-out)

On upright or horizontal panel (fixed in the frame profile)



- A** Frami bracket 60
- B** Horizontal panel
- C** Spring cotter (protection against accidental lift-out)


When the platform is fixed in the frame profile, the formwork does not provide any fall-protection.

- For this reason, mount an opposing guard-rail on the opposing formwork.

Sideguards on exposed platform-ends

On pouring scaffolds that do not completely encircle the structure, suitable sideguards must be placed across exposed end-of-platform zones.

with Handrail clamp S



- A** Handrail clamp S
- B** Guard-rail plank min. 2x4 (1 1/2" x 3 1/2" (4 x 9 cm)), site-provided
- C** Guard-rail plank min. 2x6 (1 1/2" x 5 1/2" (4 x 14 cm)), site-provided
- D** Frami bracket 60

Note:

The scaffold planks and guard-rail material shall meet or exceed any local, state, provincial or national regulations.

The sideguard consists of:

- 2 Handrail clamps S
- 2 guard-rail planks min. 1 1/2" x 3 1/2" (4 x 9 cm), site-provided
- 1 guard-rail plank min. 1 1/2" x 5 1/2" (4 x 14 cm), site-provided

How to mount:

- Fasten the handrail clamps to the deck planking of the pouring scaffold, using the wedge (clamping range 1" - 1'-5" (2 to 43 cm)).
- Secure the guardrail planks to the loops on the handrail clamps with one d10 (28x65) nail per loop.




Follow the directions in the User Information booklet "Handrail clamp S"!

Resetting by crane


Safe crane-handling of Frami is made possible by the Doka 4-part chain 3.20m and the Frami lifting hook. The lifting hook locks automatically after being hung into place.

Doka 4-part chain 3.20m




- Attach the Doka 4-part chain 3.20m to the Frami lifting hooks.
- Hang the remaining chain-lengths back in place.

Max. load-bearing capacity (as 2-part chain):
Up to spread-angle β of 30°: 5200 lbs (2400 kg).

 Follow the directions in the Operating Instructions!


Frami lifting hook



Max. load:


1100 lbs (500 kg) per Frami lifting hook

Area of formwork that can be lifted with 2 lifting hooks:
approx. 270 sq.ft. (25 m²)

 Follow the directions in the Operating Instructions!

Positioning the lifting hooks

- Never use the lifting hook to move the gangs in a horizontal position.
- Always position the lifting hook over the panel joint, to prevent the hook sliding from side to side.
Exception: On horizontally-placed panels, the lifting hook must be placed over a cross profile.
- Suspend the gang-form symmetrically (center-of-gravity position).
- Spread-angle β max. 30°!



β ... max. 30°

How to operate the lifting hook


- 1) Raise the handle (locking lever) as far as it will go.
- 2) Push the lifting hook onto the frame profile as far as the rear stop, and close the handle (spring-loaded).



Do a sight-check to make sure that there is a secure form-fit between the lifting hook and the frame profile!

The handle must be closed!

- 3) When the panels are lifted by the crane, a load-dependent locking mechanism is activated.



9231-202-01

Stripping and resetting the panels

Before lifting: Remove any loose items from the formwork and platforms, or secure them firmly.



Important note:

- Guiding the gang should be done with tag-lines that are long enough to keep the person who is doing the guiding out of the way of the gang.



Warning!

The formwork tends to adhere to the concrete. When stripping the formwork, do not try to break concrete cohesion using the crane!

Risk of crane overload.

- Use suitable tools such as timber wedges or a special pry-bar to detach the formwork from the concrete.
- Fly the gang to its next location (guide with tag-lines if necessary).

Transporting, stacking and storing

Bundling the panels


- 1) Place sleepers (W x H approx. 4" x 4" (10 x 10 cm)) under the cross profile.
- 2) Strap the sleepers and the bottom framed panel together with metal banding.



Caution!

- ▶ Stack max. 10 panels on top of one another (results in a stack height, incl. sleepers, of approx. 3'-4" (100 cm)).


- 3) Strap the whole stack together tightly with metal banding.



Transporting the panels

Dokamatic lifting strap 13.00m

The Lifting strap 13.00m is a practical tool for **offloading and loading trucks**, and for **lifting and setting down** stacks of panels.



With closely stacked bundles of panels:

- ▶ lever up the bundle of panels (e.g. with a piece of dimensional lumber (**D**)), to make a space for threading in the lifting straps.

Caution!

When doing this, always make sure that the bundle of panels remains stable!



Warning!

- ▶ The Lifting straps 13.00 m may only be used as shown here if there is no risk of the straps sliding towards one another, or of the load being displaced.

Max. load: 4400 lbs (2000 kg)




Follow the directions in the Operating Instructions!

Doka 4-part chain 3.20m

The Doka 4-part chain 3.20m is a multi-functional slinging means:

- used with the integrated **eye-hooks** for hoisting formwork, platforms and multi-trip packaging containers
- used in conjunction with **Frami transport hook 2.5kN** for hoisting stacks of panels and individual panels



The Doka 4-part chain 3.20m can be adjusted to the center-of-gravity position by shortening the lengths of the individual chains.

Max. load:


	Spread-angle β			
	0°	0°-30°	30°-45°	45°-60°
Using 1 chain	3000 lbs (1400 kg)	-	-	-
Using 2 chains	-	5200 lbs (2400 kg)	4400 lbs (2000 kg)	3000 lbs (1400 kg)
Using all 4 chains	-	7900 lbs (3600 kg)	6600 lbs (3000 kg)	4600 lbs (2120 kg)



Follow the directions in the Operating Instructions!

Frami transport hook 2.5kN with Doka 4-part chain 3.20m

Close-up of Frami transport hook 2.5kN



- A** Frami transport hook 2.5kN
- B** Doka 4-part chain 3.20m
- C** Stacking tape
- D** Strapping tape



Max. load:
550 lbs (250 kg) per Frami transport hook 2.5kN



Follow the directions in the Operating Instructions!

The Frami transport hook 2.5kN plus Doka 4-part chain 3.20m are used for:

- Hoisting bundled stacks of panels
- Lifting panels off the stack
- Handling horizontal (flat) multi-panel gangs



Dimension "b" (width of gang)	Max. n° of panels across width of gang
Up to 6'-0"	No restriction
Over 6'-0"	Max. 3 panels



Warning!

Using the Frami transport hook 2.5kN to lift either single panels or multi-panel gangs into the upright is **forbidden**.

- Use the Frami lifting hook to lift panels or gangs into the upright.

Doka multi-trip packaging

Utilize the benefits of Doka multi-trip packaging on your worksite.

Our Multi-trip packaging such as transport boxes, stacking pallets, accessory boxes and skeleton transport boxes keep everything in place on the site.


Doka multi-trip transport box 1.20x0.80m

The ideal container for all small components:

- durable
- stackable
- safe to lift by crane

The multi-trip transport box is used for delivering e.g.:

- Frami clamps
- Frami adjustable clamps
- Frami universal walings 0.70m
- Frami wedge clamps
- Frami filler angles
- Frami universal fixing bolts 5-12cm




Max. load: 3300 lbs (1500 kg)



Follow the directions in the Operating Instructions!

Multi-trip transport box partition

Different items in the Multi-trip transport box can be kept separate with the Multi-trip transport box partitions 1.20m or 0.80m.



A Slide-bolt for fixing the partition

Possible ways of dividing the box

Multi-trip transport box partition	Lengthways	Crossways
1.20m	max. 3 units	-
0.80m	-	max. 3 units

Tr755-200-04

Tr755-200-05


Column formwork with Frami

There are several different ways of using Frami framed formwork to make column formworks:


- with **universal panels**
 - for flexible accommodation to column cross-sections of up to 32" x 32" (81 x 81 cm) in 2" (5.1 cm) increments
- combining **Universal panels and standard panels**
 - is a highly economical solution for certain cross-sections of column

- with **standard panels and outside corners**
 - for the dimensions 6", 12", 18" and 24" (15.2 cm, 30.5 cm, 45.7 cm and 61 cm)

Permitted pressure of fresh concrete:
1650 psf (80 kN/m²)



Design of column formwork




- C** Super-plate 15.0
- D** Frami S frontal triangular ledge 3/4"

Frami universal fixing bolt:
 Permitted tensile load:
 3.51 kip (15.6 kN), when used in a Universal panel

Close off any unused holes in the form-ply of the Universal panels with **Frami plugs**.

Materials schedule:




- To achieve exact plumbing & aligning of the column formwork, the best arrangement of the panel struts is as shown above.
- Always attach panel struts to free-standing formwork halves to prevent them from falling over.
- To obtain the highest possible dimensional accuracy, the panels must be pushed apart (i.e. towards the outside) while being assembled.

with Universal panels

The practical 2" (5.1 cm) hole-grid is ideal for forming columns. **Cross-sections of up to 32" x 32" (81 x 81 cm)**. By combining panels with heights of 9'-0", 6'-0", 4'-0", 3'-0" and 2'-0", an incremental height grid of 1'-0" (30.5 cm) can be achieved.

Possible cross-sections in a 2" (5.1 cm) increment-grid



Formwork height (H)	Universal panel (A)					Frami clamp (B)	Universal fixing bolt (C)	Super-plate 15.0 (D)
	9'-0"	6'-0"	4'-0"	3'-0"	2'-0"			
9'-0" (2.74 m)	4					8	24	24
10'-0" (3.05 m)		4	4			8	28	28
11'-0" (3.35 m)	4				4	8	28	28
12'-0" (3.65 m)	4			4		8	32	32
13'-0" (3.96 m)	4		4			8	36	36
14'-0" (4.26 m)	4			4	4	16	36	36
15'-0" (4.57 m)	4	4				8	40	40
16'-0" (4.87 m)	4		4	4		16	44	44
17'-0" (5.18 m)	4	4			4	16	44	44
18'-0" (5.48 m)	8					8	48	48

Table gives number of items needed

A 2'-0" high Universal panel as the topmost panel requires only one Universal fixing bolt 5-12cm + Super-plate at each corner of the column.


Example: 16" x 30" (40.6 x 76.2 cm) column

- A** Universal panel
- B** Frami universal fixing bolt 5-12cm

with Universal panels and standard panels

Certain cross-sections of column can be formed highly economically by combining Universal panels and standard panels.

Possible cross-sections:



a ... up to 28" (71 cm), in 2" (5.1 cm) increments
Example: 16" x 24" (40.6 x 61 cm) column


A Frami S universal panel

B Frami S panel (max. 2'-0")

C Frami universal fixing bolt 5-12cm

D Super-plate 15.0

Materials schedule:




Formwork height (H)	Universal panel (A)				Standard panel (B)			
	9'-0"	6'-0"	4'-0"	3'-0"	9'-0"	6'-0"	4'-0"	3'-0"
3'-0" (0.91 m)				2				2
4'-0" (1.22 m)			2				2	
6'-0" (1.83 m)		2				2		
7'-0" (2.13 m)			2	2			2	2
8'-0" (2.44 m)			4				4	
9'-0" (2.74 m)	2				2			
10'-0" (3.05 m)		2	2			2	2	
11'-0" (3.35 m)			4	2			4	2
12'-0" (3.65 m)	2			2	2			2
13'-0" (3.96 m)	2		2		2		2	
14'-0" (4.26 m)		2	4			2	4	
15'-0" (4.57 m)	2	2			2	2		
16'-0" (4.87 m)	2		2	2	2		2	2
17'-0" (5.18 m)	2		4		2		4	
18'-0" (5.48 m)	4				4			

Formwork height (H)	Frami clamp (C)	Frami universal fixing bolt 5-12cm (D)	Super-plate 15.0 (E)
3'-0" (0.91 m)		8	8
4'-0" (1.22 m)		12	12
6'-0" (1.83 m)		16	16
7'-0" (2.13 m)	8	20	20
8'-0" (2.44 m)	8	24	24
9'-0" (2.74 m)		24	24
10'-0" (3.05 m)	8	28	28
11'-0" (3.35 m)	16	32	32
12'-0" (3.65 m)	8	32	32
13'-0" (3.96 m)	8	36	36
14'-0" (4.26 m)	16	40	40
15'-0" (4.57 m)	8	40	40
16'-0" (4.87 m)	16	44	44
17'-0" (5.18 m)	16	48	48
18'-0" (5.48 m)	8	48	48

Table gives number of items needed

with outside corners and standard panels

The dimensions **6"**, **12"**, **18"** and **24"** (15.2 cm, 30.5 cm, 45.7 cm and 61 cm) can also be formed with **outside corners** and **standard panels**.





Example: 18" x 18" (45.7 x 45.7 cm) column

- A** Frami S panel (max. 2'-0")
- B** Frami S outside corner
- C** Frami clamp
- D** Triangular chamfer

Materials schedule:

up to 18" (45.7 cm)

up to 24" (61 cm)



Example: Outside corners 9'-0" with framed formwork panels 1'-6" x 9'-0"

Example: Outside corners 9'-0" with framed formwork panels 2'-0" x 9'-0" and separate Frami clips

Important note:


For 24" (61 cm) wide columns, 4 Frami clips for every 9'-0" (2.74 m) of column height are also required in the Frami outside corner.

Panel height (H)	Standard panel (A)				Outside corner (B)				Frami clamp (C)
	9'-0"	6'-0"	4'-0"	3'-0"	9'-0"	6'-0"	4'-0"	3'-0"	
3'-0"				4				4	16
4'-0"			4				4		24
6'-0"		4				4			32
9'-0"	4				4				48

Table gives number of items needed


with outside corners and universal panels

Columns with a **36" (91.5 cm)** width can be formed using **outside corners** and **universal panels**.



- A** Frami S universal panel
- B** Frami S outside corner
- C** Frami clamp
- D** Frami clip
- E** Triangular chamfer

Materials schedule:




Example: Outside corners 9'-0" with Universal panels 3'-0"x9'-0"

Panel height (H)	Universal panel (A)				Outside corner (B)				Frami clamp (C)	Frami clip (D)
	9'-0"	6'-0"	4'-0"	3'-0"	9'-0"	6'-0"	4'-0"	3'-0"		
3'-0"				4				4	16	16
4'-0"			4				4		24	16
6'-0"		4				4			32	24
9'-0"	4				4				48	32

Table gives number of items needed

with column hinge and standard panels

The Frami S column hinge makes for **easy opening and closing** of the column formwork. This does away with time-consuming assembly and dismantling work. In conjunction with standard panels and outside corners, they can be used to form columns with widths of **6", 12", 18"** and **24"** (15.2 cm, 30.5 cm, 45.7 cm and 61 cm).




9777-399-01

Example: 18" x 18" (45.7 x 45.7 cm) column


- A** Frami S panel (max. 2'-0")
- B** Frami S outside corner
- C** Frami clamp
- D** Frami S column hinge
- E** Hexagon bolt DIN 933 M18x50 8.8 galv. + Hexagon nut DIN 934 M18 8 galv.

Materials schedule:

Example with standard panel 1'-6"x9'-0"



Example with standard panel 2'-0"x9'-0"



Important note:


- For 24" (61 cm) wide columns, 4 Frami clips for every 9'-0" (2.74 m) of column height are also required in the Frami outside corner.
- For 24" (61 cm) wide columns, 4 bolts for every 9'-0" (2.74 m) of column height are also required in the Frami column hinge.

Panel height (H)	Standard panel (A)				Outside corner (B)			
	9'-0"	6'-0"	4'-0"	3'-0"	9'-0"	6'-0"	4'-0"	3'-0"
3'-0"				4				3
4'-0"			4				3	
6'-0"		4				3		
9'-0"	4				3			

Panel height (H)	Column hinge (D)			Hexagon bolt + hexagon nut (E)	Frami clamp (C)
	6'-0"	4'-0"	3'-0"		
3'-0"			1	6	12
4'-0"		1		8	18
6'-0"	1			12	24
9'-0"	1		1	18	36

Table gives number of items needed

Pouring platform with Frami bracket 60



- A Frami bracket 60 (floor and railing planking provided at site)
- B Handrail clamp S (railing planking provided at site)
- C Board for screwing the floor planking onto

Note:

Where the two floor planking units meet, a board must be screwed onto the underside.


For more information on constructing pouring platforms, see "Pouring platforms with single brackets".

Footing and grade beam formwork

The Frami panels can also be used for footings and grade beams.

This is particularly advantageous where it is intended to continue forming (i.e. the walls) using the same panels. Footings and grade beams can quickly be formed with any of the Frami panels, with the panels either upright

or horizontal. Frami clamps, and a blow with the hammer, are all it takes to join the panels. Length adjustments and corners are solved just as simply as in "normal" walls. A range of practical accessories makes the work very much easier.





Design of the footing and grade beam formwork

Horizontal framed panels

Tying the panels

- **at top:** with Frami S top yoke (A) and Frami clip (B)
- **at bottom:** with Frami foundation clamp (C) and Doka perforated tape (D)

In this way, there is no need to place form-ties through the concrete.



Frami S top yoke 4"-30":

Permitted capacity: 1.12 kip (5.0 kN)

Frami clip:

Permitted tensile force: 2.245 kip (10.0 kN)


Permitted shear force: 1.12 kip (5.0 kN)

Permitted moment: 0.15 kip-ft (0.20 kNm)

Frami foundation clamp:

Permitted capacity: 1.795 kip (8.0 kN)

Doka perforated tape



Z ... Length of tape cut off roll: Wall thickness + 15 3/4" (40 cm)

	a	b	c
Doka perforated tape S 2" 25m	3/4"	2"	2"
Doka perforated tape 50x2.0mm 25m	18 mm	5 cm	5 cm

Top tie

Frami top yoke and Frami clip

- These fix the spacing between the panels and
- permit wall thicknesses of 4" - 30" (10 - 76 cm), in 2" (5.1 cm) increments

Number of Frami top yokes (rule-of-thumb):

Horizontal 3'-0" and 4'-0" panels:

- 1 in each panel
- 2 in the first panel and the last panel

Horizontal 6'-0" and 9'-0" panels:

- 2 in each panel

Bottom tie

Doka perforated tape and Frami foundation clamp:

- These fix the spacing between the panels and
- permit wall thicknesses in 2" (5.1 cm) increments

Number of Doka-perforated tapes (rule-of-thumb):

On horizontal panels **up to a formwork height of 2'-6" (76 cm):**



- 1 per 3'-0" or 4'-0" panel
 - right next to the panel joint
- 2 per 6'-0" panel
 - right next to the panel joint
- 2 per 9'-0" panel
 - each 2'-0" (61 cm) from the panel joint

On horizontal panels **up to a formwork height of 3'-0" (91 cm):**

- 1 per 3'-0" panel
 - right next to the panel joint
- 2 for each 4'-0" or 6'-0" panel
 - right next to the panel joint
- 3 per 9'-0" panel
 - 2 right next to the panel joint
 - 1, located 4'-0" (122 cm) from the panel joint


Practical example

Framed panel 3'-0"x3'-0"



- A** Frami S top yoke
- B** Frami clip
- C** Frami foundation clamp
- D** Doka perforated tape (expandable)
- E** Frami panel 3'-0"x3'-0"

Framed panel 2'-0"x9'-0"



Framed panel 3'-0"x9'-0"



Horizontal Universal panels

Tying the panels

- **In the panel:** with Taper tie 3/4" to 1" & 5/8" [15.0] ends


This makes it possible to tie the panels above a joint-sealing tape. The max. tying height is 1'-0" (30 cm) - do not place the tie higher than this!

Pressure bracing


- **At top:** with Frami top yoke (A) and Frami clip (B)

Practical example

Universal panel 3'-0"x6'-0"




- a ... max. tying height = 1'-0" (30 cm)
- b ... 3'-0" (91 cm)



- A** Form-tie 15.0
- B** Frami top yoke
- C** Frami clip
- D** Frami Universal panel
- E** Joint-sealing tape

Universal panel 3'-0"x9'-0"



- a ... max. tying height = 1'-0" (30 cm)
- b ... 3'-0" (91 cm)

Upright panels

Variant 1 - with top yoke and perforated tape

- **At top:** with Frami top yoke and Frami clip
- **At bottom:** with Frami foundation clamp and Doka perforated tape

Panel width	Max. pour height
3'-0"	3'-2" (96 cm)
2'-6"	3'-6" (106 cm)
2'-0"	4'-0" (122 cm)

Number of Frami top yokes (rule-of-thumb):

Upright panels: **3'-0" and 4'-0"**:

- 1 per panel
 - right next to the panel joint


Number of Doka-perforated tapes (rule-of-thumb):

Upright panels: **3'-0" and 4'-0"**:

- 1 per panel
 - above the panel joint

with Frami anchoring bracket



- **At top:** with Frami anchoring bracket (A) and Taper tie 3/4" to 1" & 5/8" [15.0] ends (B)
 - enables the form-tie to be placed above the framed panel
 - tie-rods cannot be knocked off; anchor-plate cannot slide out of position
- **In the panel:** with Taper tie 3/4" to 1" & 5/8" [15.0] ends



Position of the Frami anchoring bracket (normally):

Always above the panel joint.

Practical example



A Frami anchoring bracket


B Form-tie

C Wooden spacer

Plumbing accessories

The Doka plumbing accessories are the safe, reliable way to set up and plumb the panels of the footing and grade beam formwork.


Plumbing the panels with the Frami plumbing strut 260



a ... min. 4'-9" (145 cm)

For more information, see the section headed "Plumbing accessories".

Plumbing the panels with the Adjusting strut 120



a ... min. 2'-7 1/2" - max. 4'-3" (80 - 130 cm)


A Adjusting strut 120

B Frami strut head


C Strut shoe for Frami plumbing strut 260

Frost walls

1st casting section



2nd casting section



A Frami S panel 4'-0"

B Frami S panel 6'-0"

C She-bolt 7/8"x19"

D Super-plate 20.0 B

E Tie rod 15.0mm

F Wooden spacer

G Frami plumbing strut 260

Notes

A large grid of graph paper for taking notes, consisting of 30 columns and 40 rows of small squares.

Cleaning and care of your equipment

To keep formwork cleaning costs as low as possible, please observe the following:

Concrete release agent

Before every pour

- Apply release agent to the formwork sheet and the end faces **extremely thinly, evenly** and **in a continuous layer** (make sure there are no traces of release-agent running down the formwork sheet)! Applying too much release agent will spoil the concrete finish.




To determine the right dosage and to make sure that you are using the agent correctly, test it on less important parts of the structure first.

Cleaning

Immediately after pouring

- Remove any blobs of concrete from the back-face of the formwork, using water (without any added sand).




Immediately after stripping the formwork

- Clean the formwork with a concrete scraper.



Cleaning equipment

Concrete scraper

For removing any concrete remnants, we recommend using a **Double scraper Xlife** and a spatula.



Functional description:




A Blade for dealing with heavy soiling

B Blade for dealing with slight soiling


Note:

Do not use any pointed or sharp objects, wire brushes, rotating grinding disks or pan scourers.




Care


- No hammer-blows to the frame profiles



- Never push over panels or allow them to fall



- Only stack panel gangs on top of one another with timber battens (A) between each layer.




This prevents the formwork sheets from being damaged by the connector components.

Frami combined with . . .

Starting block D22

With the Starting block of the Dam formwork D22, you can also use the Frami panels for single-sided wall formwork.



- A** Starter-block unit D22
- B** Vertical waling D15 3.00 m U120
- C** Spindle strut D15 3.00 m
- D** Screw-on access bracket MF75
- E** Frami S panel



Follow the directions in the “Doka dam formwork” User Information!

Doka service offerings

Doka Reconditioning Service

So that your formwork is in "top form" for its next assignment


Inspecting, cleaning and maintaining your Doka framed formwork - all jobs which the Doka Reconditioning Service will be pleased to take care of for you. Its highly qualified staff and special equipment will soon get your formwork back in top form, quickly and economically.

The big benefit for you: You always have formwork that is **ready for use**, and also **extend the service life** of your equipment.

What's more: It is only with well-maintained formwork that you will achieve the desired quality of concrete surface.

In our modern plants, your formwork will be **carefully cleaned** using energy-saving and environmentally sound technology.

The panels are then inspected for damage and dimensional accuracy, and overhauled where necessary. Any damaged form-ply is repaired, or - if necessary - replaced.



Doka customer training

Formwork training pays

Forming operations account for the lion's share of labor costs on concrete construction sites. Modern formwork equipment helps to rationalize operations. By improving the overall construction sequence at the same time, however, further very worthwhile gains in efficiency can be achieved.

This requires not only better equipment, but also greater skill in making optimum use of this equipment. Doka can help here, with its specialist training program - to help each and every member of the team do his bit towards boosting efficiency and lowering costs.


Doka customer training events also look at the formwork equipment and handling methods that are needed in order to achieve optimum safety - giving your people knowledge and awareness which can only enhance workplace safety on the site.

You'll find the Doka training program well worth looking into.

The Doka branch in your region will be pleased to tell you more about Doka's various training offerings.


	[lbs]	Article #
Frami S panel 3'-0"x9'-0"	175.0	588801000
Frami S panel 2'-6"x9'-0"	158.0	588802000
Frami S panel 2'-0"x9'-0"	133.0	588803000
Frami S panel 1'-6"x9'-0"	113.0	588804000
Frami S panel 1'-0"x9'-0"	95.0	588805000
Frami S panel 6"x9'-0"	59.5	588806000
Frami S panel 3'-0"x6'-0"	122.0	588811000
Frami S panel 2'-6"x6'-0"	107.0	588812000
Frami S panel 2'-0"x6'-0"	91.3	588813000
Frami S panel 1'-6"x6'-0"	77.2	588814000
Frami S panel 1'-0"x6'-0"	64.8	588815000
Frami S panel 6"x6'-0"	44.1	588816000
Frami S panel 3'-0"x4'-0"	86.0	588854000
Frami S panel 2'-6"x4'-0"	75.0	588855000
Frami S panel 2'-0"x4'-0"	64.6	588856000
Frami S panel 1'-6"x4'-0"	50.5	588857000
Frami S panel 1'-0"x4'-0"	46.3	588858000
Frami S panel 6"x4'-0"	28.7	588859000
Frami S panel 3'-0"x3'-0"	67.5	588821000
Frami S panel 2'-6"x3'-0"	60.2	588822000
Frami S panel 2'-0"x3'-0"	52.9	588823000
Frami S panel 1'-6"x3'-0"	44.3	588824000
Frami S panel 1'-0"x3'-0"	36.6	588825000
Frami S panel 6"x3'-0"	21.4	588826000

Frami S-Rahmenelement
Galvanized




	[lbs]	Article #
Frami S inside corner 1'-0"x9'-0"	138.0	588817000
Frami S inside corner 1'-0"x6'-0"	94.4	588818000
Frami S inside corner 1'-0"x4'-0"	66.8	588861000
Frami S inside corner 1'-0"x3'-0"	54.0	588819000

Frami S-Innenecke
Galvanized




	[lbs]	Article #
Frami S outside corner 9'-0"	54.0	588827000
Frami S outside corner 6'-0"	35.5	588828000
Frami S outside corner 4'-0"	24.3	588862000
Frami S outside corner 3'-0"	17.4	588829000

Frami S-Außenecke
Galvanized




	[lbs]	Article #
Frami S universal panel 3'-0"x9'-0"	221.0	588807000
Frami S universal panel 3'-0"x6'-0"	158.0	588808000
Frami S universal panel 3'-0"x4'-0"	108.0	588860000
Frami S universal panel 3'-0"x3'-0"	81.6	588809000
Frami S universal panel 3'-0"x2'-0"	52.9	588810000

Frami S-Universalelement
Galvanized
Corners marked in blue



	[lbs]	Article #
Frami S pilaster panel 9'-0"	197.0	588838000
Frami S pilaster panel 6'-0"	139.5	588839000
Frami S pilaster panel 4'-0"	99.2	588865000
Frami S pilaster panel 3'-0"	55.3	588840000


Frami S-Stützevorlageelement
Powder-coated, blue
Length: 2' (61 cm)
Width: 6" (15 cm)



	[lbs]	Article #
Frami S hinged inside corner I 9'-0"	157.0	588831000
Frami S hinged inside corner I 6'-0"	104.0	588832000
Frami S hinged inside corner I 4'-0"	75.0	588863000
Frami S hinged inside corner I 3'-0"	60.0	588833000

Frami S-Scharnierecke I


Powder-coated, blue



Frami S hinged outside corner A 9'-0"	64.4	588834000
Frami S hinged outside corner A 6'-0"	42.5	588835000
Frami S hinged outside corner A 4'-0"	28.7	588864000
Frami S hinged outside corner A 3'-0"	21.6	588836000


Frami S-Scharnierecke A

Powder-coated, blue



Frami S column hinge 6'-0"	31.5	588881000
Frami S column hinge 4'-0"	20.9	588882000
Frami S column hinge 3'-0"	15.7	588883000

Frami S-Stützengelenk



Hexagon bolt DIN 933 M18x50 8.8 galv. Sechskantschraube DIN 933 M18x50 8.8 verz.	0.33	588879000
--	------	-----------




Hexagon nut DIN 934 M18 8 galv. Sechskantmutter DIN 934 M18 8 verz.	0.11	588880000
---	------	-----------



	[lbs]	Article #
Frami S steel filler 2"x9'-0"	22.5	588842000
Frami S steel filler 1 1/2"x9'-0"	20.9	588843000
Frami S steel filler 1"x9'-0"	15.4	588844000
Frami S steel filler 2"x6'-0"	15.0	588845000
Frami S steel filler 1 1/2"x6'-0"	13.9	588846000
Frami S steel filler 1"x6'-0"	9.3	588847000
Frami S steel filler 2"x4'-0"	11.0	588866000
Frami S steel filler 1 1/2"x4'-0"	10.4	588867000
Frami S steel filler 1"x4'-0"	7.5	588868000
Frami S steel filler 2"x3'-0"	9.7	588848000
Frami S steel filler 1 1/2"x3'-0"	8.6	588849000
Frami S steel filler 1"x3'-0"	6.4	588850000

Frami S-Stahlausgleich

Powder-coated, blue



Frami S filler angle 3/4" 3'-0"	7.3	588820000
Frami S filler angle 3/4" 4'-0"	10.4	588860000
Frami S filler angle 3/4" 6'-0"	15.4	588885000
Frami S filler angle 3/4" 9'-0"	23.6	588884000

Frami S-Schalhautwinkel


Galvanized



Framax S bias cut corner I 2.70m	388.0	588527000
Framax S bias cut corner I 1.35m	207.0	588528000

Framax S Ausschalecke I

Galvanized, powder-coated



Framax stripping spindle I with ratchet	12.1	588653000
--	------	-----------

Framax-Ausschalspindel I mit Ratsche

Galvanized

Height: 10" (24,8 cm)



















Frami tie-adapter for bias cut corner I	1.0	588492000
--	-----	-----------













Frami-Ankeradapter für Ausschalecke I









Galvanized







Height: 4 1/2" (11 cm)


















		[lbs]	Article #			[lbs]	Article #		
Frami profile adapter for bias cut corner I Frami-Profiladapter für Ausschalecke I		Galvanized Height: 3 1/4" (8 cm)	1.3	588491000	Frami profile connector 5-18cm Frami-Profilverbinder 5-18cm		Galvanized Length: 1'-1" (33 cm)	1.8	588493000
Framax quick acting clamp RU Framax-Schnellspanner RU		Galvanized Length: 8" (20 cm)	7.3	588153400	Frami lifting hook Frami-Umsetzbügel		Galvanized Width: 6" (15 cm) Height: 8" (21 cm) Max. load: 1,100 lbs (500 kg) Follow the directions in the "Operating Instructions"!	16.5	588438000
Frami panel shoe Frami-Elementschuh		Galvanized Length: 6 1/2" (16 cm)	2.9	588490000	Frami plumbing strut 260 Frami-Justierstütze 260		Galvanized Length: 4'-9" - 8'-6" (145 - 258 cm) Observe all applicable safety regulations.	30.6	588437000
Frami clamp Frami-Spanner		Galvanized Length: 4 1/2" (11 cm)	2.6	588433000	Adjusting strut 120 Justierstrebe 120		Galvanized Length: 2'-7" - 4'-3" (80 - 130 cm) Observe all applicable safety regulations.	15.9	588248000
Frami adjustable clamp Frami-Ausgleichsspanner		Galvanized Length: 1'-4" (40 cm) Never weld or heat tie-rods - risk of fracture!	7.9	588436000	Strut shoe for Frami plumbing strut 260 Strebenschuh f. Frami-Justierstütze 260		Galvanized Width: 3 1/4" (8 cm) Height: 5" (13 cm)	1.8	508437030
Frami universal waling 0.70m Frami universal waling 1.25m Frami-Klemmschiene		Painted blue	8.2 14.1	588439000 588440000	Strut 340 Stütze 340 consisting of:		Galvanized Delivery condition: separate parts Observe all applicable safety regulations.	31.3	588247000
Framax S universal waling 0.90m Framax S universal waling 1.50m Framax S Klemmschiene		Painted blue	23.6 39.2	588519000 588520000	(A) Plumbing strut 340 Galvanized Length: 6'-3" - 11'-2" (190 - 341 cm)			4.6	588245000
Frami wedge clamp Frami-Klemme		Galvanized Length: 6 1/2" (16 cm)	2.4	588441000	(B) Prop shoe Galvanized Length: 8" (20 cm) Width: 4 1/2" (11 cm) Height: 4" (10 cm)				
Frami universal fixing bolt 5-12cm Frami-Universalverbinder 5-12cm		Galvanized Length: 9" (23 cm) Packed in units of 50	0.95	588479000					

	[lbs]	Article #		[lbs]	Article #			
<p>Strut 540 Stütze 540 consisting of:</p> <p>(A) Plumbing strut 540 Galvanized Length: 10'-2" - 18'-1" (309 - 550 cm)</p> <p>(B) Prop shoe Galvanized Length: 8" (20 cm) Width: 4 1/2" (11 cm) Height: 4" (10 cm)</p>  <p>Galvanized Delivery condition: separate parts Observe all applicable safety regulations.</p>	65.3	588250000						
<p>Pipe brace 12'-0"-21'-0" Elementstütze 12'-0"-21'-0" consisting of:</p> <p>(A) Pipe brace 12'-0"-21'-0" Galvanized Length: 12'-0" - 21'-0" (366 - 640 cm)</p> <p>(B) Speed bolt 3/4"x4" 2 pcs.</p> <p>(C) Speed nut 3/4" 2 pcs.</p> <p>(D) Pipe brace shoe</p>  <p>Galvanized Delivery condition: separate parts Observe all applicable safety regulations.</p>	160.0	585091000	0.64	585650000	0.2	585652000	10.4	585088000
<p>Frami strut head Frami-Strebenkopf</p>  <p>Galvanized Width: 3 1/2" (9 cm) Height: 5 1/2" (14 cm)</p>	3.1	508437002						
<p>Frami S bracing head Frami S-Stützenkopf</p>  <p>Galvanized Width: 7 1/2" (19 cm) Height: 7 1/2" (19 cm)</p>	9.7	588853000						
<p>Frami S connection profile Frami S-Anschlussprofil</p>  <p>Painted blue Length: 3'-5" (105 cm)</p>	22.0	588852000						
<p>Doka express anchor 16x125mm Doka-Expressanker 16x125mm</p>  <p>Galvanized Length: 7" (18 cm) Packed in units of 10 Follow fitting instructions!</p>	0.68	588631000						
<p>Doka coil 16mm Doka-Coil 16mm</p>  <p>Galvanized Diameter: 5/8" (1,6 cm) Packed in units of 100 Follow fitting instructions!</p>	0.02	588633000						
<p>Frami bracket 60 Frami-Konsole 60</p>  <p>Galvanized Length: 3'-3" (98 cm) Height: 5'-2" (157 cm) Observe all applicable safety regulations.</p>	17.0	588442000						
<p>Handrail clamp S Schutzgeländerzwinde S</p>  <p>Galvanized Height: 4' - 5'-7" (123 - 171 cm)</p> 	25.4	580470000						
<p>Frami S frame hole plug Frami S-Ankerstopfen</p>  <p>Brown Diameter: 1 1/8" (3 cm)</p>	0.007	588830000						
<p>Frami universal panel plug Frami-Abdeckstopfen</p>  <p>Brown Diameter: 3/4" (2 cm)</p>	0.007	588445000						

	[lbs]	Article #
Frami anchoring bracket Frami-Ankerhaltewinkel  Galvanized Packed in units of 20	1.3	588453000
Frami S top yoke 4"-30" Frami S-Flachanker 4"-30"  Galvanized Length: 3'-3" (99 cm)	4.9	588837000
Frami clip Frami-Stecker  Galvanized Width: 1 1/8" (3 cm) Height: 4 1/2" (12 cm) Packed in units of 60	0.57	588434000
Frami foundation clamp Frami-Fundamentspanner  Galvanized Height: 3 1/2" (9 cm)	3.5	588452000
Doka perforated tape S 2" 25m Doka-Lochband S 2" 25m  Perm. capacity: will depend on the foundation clamp of the formwork system used.	37.5	588841000
Doka perforated tape 50x2.0mm 25m Doka-Lochband 50x2,0mm 25m  Perm. capacity: will depend on the foundation clamp of the formwork system used.	37.5	588206000
Frami S frontal triangular ledge 3/4" 9'-0" Frami S frontal triangular ledge 3/4" 6'-0" Frami S frontal triangular ledge 3/4" 4'-0" Frami S frontal triangular ledge 3/4" 3'-0" Frami S frontal triangular ledge 3/4" 2'-0" Frami S-Stirndreikantleiste 3/4" 	3.7 2.4 1.7 1.2 0.82	588878000 588877000 588876000 588875000 588874000
Doka 4-part chain 3.20m Doka-Vierstrangkette 3,20m  Max. load: With angle of inclination β 30°: 5200 lbs (2400 kg) with 2 cables or 7900 lbs (3600 kg) with 4 cables Follow the directions in the "Operating Instructions"!	33.1	588620000

	[lbs]	Article #
Frami transport hook 2.5kN Frami-Transporthaken 2,5kN  Galvanized Length: 7" (17,5 cm) Max. load: 550 lbs (250 kg) Follow the directions in the "Operating Instructions"!	1.1	588494000
Dokamatic lifting strap 13.00m Dokamatic-Umsetzgurt 13,00m  Green Max. load: 4,400 lbs (2000 kg) Follow the directions in the "Operating Instructions"! The GS safety mark only applies to the strap itself!	23.1	586231000
Doka multi-trip transport box 1.20x0.80m Doka-Mehrwegcontainer 1,20x0,80m  Galvanized Height: 2'-7" (78 cm) Max. load: 3,300 lbs (1500 kg) Follow the directions in the "Operating Instructions"!	165.0	583011000
Multi-trip transport box partition 0.80m Multi-trip transport box partition 1.20m Mehrwegcontainer Unterteilung  Timber parts varnished yellow Steel parts galvanized	8.2 12.1	583018000 583017000
Taper tie system 3/4" to 1"  Perm. capacity with safety factor of 2: 18,000 lbs (80,07 kN) Never weld or heat tie-rods - risk of fracture!	4.0 4.9 6.0 7.9	585820000 585821000 585822000 585823000
Super plate 15.0 Superplatte 15,0  Galvanized Height: 2 1/4" (6 cm) Diameter: 4 1/2" (12 cm) Width-across: 27 mm Packed in units of 800 Perm. capacity with safety factor of 2: 22,000 lbs (97,87 kN) Breaking load: > rod breaking load (> 43,830 lbs) (195 kN)	4.4	581966000

	[lbs]	Article #		[lbs]	Article #
She-bolt system 7/8"					
Frami S she-bolt 7/8"x19" Frami S-Ankerkopf 7/8"x19"	3.7	588873000	 <p>Perm. capacity with safety factor of 2: 18,000 lbs (80,07 kN) Never weld or heat tie-rods - risk of fracture!</p>		
Super plate 20.0 B Superplatte 20,0 B	4.4	581424000	 <p>Galvanized Height: 2 3/4" (7 cm) Diameter: 5 1/2" (14 cm) Width-across: 34 mm Packed in units of 400 Perm. capacity with safety factor of 2: 38,000 lbs (169,05 kN) Breaking load: > rod breaking load (> 79,580 lbs) (354 kN))</p>		
Form tie system 15.0					
Tie rod 15.0mm galvanized 0.50m	1.6	581821000			
Tie rod 15.0mm galvanized 0.75m	2.4	581822000			
Tie rod 15.0mm galvanized 1.00m	3.1	581823000			
Tie rod 15.0mm galvanized 1.25m	4.0	581826000			
Tie rod 15.0mm galvanized 1.50m	4.9	581827000			
Tie rod 15.0mm galvanized 1.75m	5.5	581828000			
Tie rod 15.0mm galvanized 2.00m	6.4	581829000			
Tie rod 15.0mm galvanizedm	3.1	581824000			
Tie rod 15.0mm non-treated 0.50m	1.6	581870000			
Tie rod 15.0mm non-treated 0.75m	2.4	581871000			
Tie rod 15.0mm non-treated 1.00m	3.1	581874000			
Tie rod 15.0mm non-treated 1.25m	4.0	581886000			
Tie rod 15.0mm non-treated 1.50m	4.6	581876000			
Tie rod 15.0mm non-treated 1.75m	5.5	581887000			
Tie rod 15.0mm non-treated 2.00m	6.4	581875000			
Tie rod 15.0mm non-treated 2.50m	7.9	581877000			
Tie rod 15.0mm non-treated 3.00m	9.5	581878000			
Tie rod 15.0mm non-treated 3.50m	11.0	581888000			
Tie rod 15.0mm non-treated 4.00m	12.6	581879000			
Tie rod 15.0mm non-treated 5.00m	15.9	581880000			
Tie rod 15.0mm non-treated 6.00m	19.0	581881000			
Tie rod 15.0mm non-treated 7.50m	23.6	581882000			
Tie rod 15.0mm non-treatedm	3.1	581873000			
Ankerstab 15,0mm			 <p>Perm. capacity with safety factor of 2: 22,000 lbs (97,87 kN) Breaking load: 43,830 lbs (195 kN) Never weld or heat tie-rods - risk of fracture!</p>		
Super plate 15.0 Superplatte 15,0	4.4	581966000	 <p>Galvanized Height: 2 1/4" (6 cm) Diameter: 4 1/2" (12 cm) Width-across: 27 mm Packed in units of 800 Perm. capacity with safety factor of 2: 22,000 lbs (97,87 kN) Breaking load: > rod breaking load (> 43,830 lbs) (195 kN))</p>		
Wing nut 15.0 Flügelmutter 15,0	0.68	581961000	 <p>Galvanized Length: 4" (10 cm) Height: 2" (5 cm) Width-across: 27 mm Packed in units of 60 Perm. capacity with safety factor of 2: 22,000 lbs (97,87 kN) Breaking load: > rod breaking load (> 43,830 lbs) (195 kN))</p>		
Angle anchor plate 12/18 Winkelplatte 12/18	2.9	581934000	 <p>Galvanized Packed in units of 12 Perm. load with safety factor of 2: 21,000 lbs (mounted on steel) Perm. load to DIN 18216: 19,840 lbs (mounted on steel), 6,600 lbs (mounted on timber) Special order only!</p>		
Tie rod wrench 15.0/20.0 Ankerstabschlüssel 15,0/20,0	4.2	580594000	 <p>Galvanized Length: 1'-3" (37 cm) Diameter: 3 1/4" (8 cm)</p>		
Plastic tube 22mm 2.50m Kunststoffrohr 22mm 2,50m	0.99	581951000			
Universal cone 22mm Universal-Konus 22mm	0.011	581995000	 <p>Gray Diameter: 1 5/8" (4 cm) Packed in units of 500</p>		
Plug 22mm Verschlussstopfen 22mm	0.007	581953000	 <p>Gray Packed in units of 1000</p>		

Notes

A large grid of graph paper, consisting of approximately 30 columns and 40 rows of small squares, intended for taking notes.

Notes

A large grid of graph paper for taking notes, consisting of 30 columns and 40 rows of small squares.

Frami - the super-sturdy, room-high manhandled formwork

Walls, columns and footings & grade beams can all be swiftly and easily formed by hand using the story-high panels of the Frami system. Their hot-dip galvanized, torsion-proof steel frames make for plane concrete surfaces and long formwork service life.



48575 Downing Street
Wixom, MI 48393

800.876.4857

info@formtechinc.com
formtechinc.com

Give us a call at any of our branch locations, email us at info@formtechinc.com, or click on formtechinc.com/quote to get a quote. Our experienced Form Tech representatives will answer your questions, and help you get your project started with some of the best concrete forming, shoring, and accessory products in the industry, backed by a professional and detail-oriented staff.



Charleston, SC

7377 Peppermill Lane
North Charleston,
SC 29418
843.628.3434



Detroit, MI

Corporate Headquarters
975 Ladd Road
Walled Lake,
MI 48390
Branch: 248.344.8260
Corporate: 248.344.8265



Charleston, WV

161 Industrial Road
St. Albans,
WV 25177
304.722.6804



Pittsburgh, PA

2850-A Kramer Road
Gibsonia,
PA 15044
412.331.4500



Charlotte, NC

1000 Thomasboro Road
Charlotte,
NC 28208
704.395.9910



Raleigh, NC

115 Peffinder Lane
Raleigh,
NC 27603
919.833.0911



Cleveland, OH

20801 Miles Road
North Randall,
OH 44128
216.692.0497



TRUSTED FORMWORK & ACCESSORY SPECIALISTS

800-876-4857 | info@formtechinc.com | formtechinc.com